

## Car Cup Holder

### INSTRUCTIONS ON HOW TO USE:



### UPPER CUP HOLDER ADJUSTMENT:

The product can expand and contract to fit any size cup (74mm to 150mm). The separate adjustment allows for a more accurate fitment, securing the cup in place.



### LOWER CUP HOLDER ADJUSTMENT:

To use the additional lower cup holder, simply rotate the upper cup holder to reveal the lower one.

### FITTING INSTRUCTIONS:



1. Stick the foam pad on the edge and sides. To create a tight fit for the cup holder.



2. Place into car's cup holder and make sure the fit is tight. If loose repeat step one by placing more foam pads where needed.



3. Rotate the upper cup holder to reveal lower cup holder. Expand the cup holder to fit.