

Seat Covers Full Set


FITTING INSTRUCTIONS:




1. Remove the front seat headrests, slip the seat cover over the top of the seat, and pull it into place.



2. Pull the cover over the base of the front seat, ensuring it is centred from side to side, and feed the elastics at the front of the cover under the seat toward the back with the hooks provided.




3. Cover all the headrests with the headrest cover and insert the front seat headrests.




4. Remove the headrest at the back seat.




5. Pull the cover over the base of the back seat, ensuring it is centred from side to side.



6. Tie/tape the ties onto the framework on the reverse/underside of both sections. Use the provided hooks to secure. If the backrest cannot be removed, ensure the seat cover is well tucked in between the seat back and the rear parcel shelf toward the back.



7. Cut holes in the rear seat cover for the headrests. Test the fit of the headrests through the holes and make adjustments if needed.



8. Insert the back seat headrest.